

Tree protection

Location of trees, categorisation & protection/management proposals

Land adjacent to Stanbury House, Reading

Barrell Plan Ref: 15369-9

Client Plan Refs:
T001 (2018-04-11) 11828CF1 & 11828CF2
T002 (2018-04-08) BC108855-014a.dwg
Completed phase (2022-03-30) 1198-P01 Rev 2
L001 (2022-03-09) 1070548-01 Rev B

Permission is granted to scale from this drawing for Local Authority Planning Approval purposes relating to tree protection measures only. Where applicable this drawing is to be read in conjunction with the arboricultural report. This drawing is the copyright of Barrell Tree Consultancy 2020 ©
This drawing to be reproduced in colour only.

b

barrell

TREE CONSULTANCY

www.barrelltreecare.co.uk

BS category A

Trees of high quality

BS category B

Trees of moderate quality

BS category C

Trees of low quality

BS category U

Trees unsuitable for retention

TX

Trees to be removed

Proposed layout

Estimated tree positions not included on original land survey and/or adjusted crown spreads

Protective barrier/fencing

Construction exclusion zone (CEZ)

Precautionary Areas

Veteran tree buffer zone

Root protection area (RPA) boundaries for category A and B trees

Root protection area (RPA) boundaries for category C trees

Attention: LDA Tree Officer - if you would like a 'to scale' printed version of this plan please contact us on 01425 651470 or email 'enquiries@barrelltreecare.co.uk'

SGN 1

Monitoring tree protection

Always:

have a pre-commencement meeting with the tree consultant before development starts

use the tree consultant to regularly check that protection remains fit for purpose

use the tree consultant to supervise work in RPAs

keep a written record of supervision

SGN 2

Fencing protected trees

Always:

install protection before development starts

make sure protection is fit for purpose, i.e. it prevents damage to trees and soil

keep protection in place until there is no risk to trees

get written permission to move or remove any protection

SGN 4

Pollution control

Always:

keep toxic products away from RPAs

SGN 9

Installing/upgrading surfacing in RPAs

Always:

use the tree consultant to supervise work in RPAs

minimise damage to roots and disturbance to soil in RPAs

minimise excavation when installing or upgrading surfacing in RPAs

SGN 11

Installing services in RPAs

Always:

use the tree consultant to supervise work in RPAs

select the least damaging option when installing services, so prioritise trenchless, over broken trench over continuous trench

hand-dig trenches if trenchless is not feasible

SGN 12

Landscaping in RPAs

Always:

use the tree consultant to supervise work in RPAs

avoid raising ground levels within 1m of the trunks of retained trees

How to use plan

More detailed guidance on each Site Guidance Note (SGN) can be found in a printed hard copy compilation of all the SGNs, Manual for Managing Trees On Development Sites version 3.0, issued to the Site Manager at the pre-commencement site meeting (Note: This should be retained on site throughout the duration of works). Additionally, an electronic pdf compilation of all the SGNs, was submitted with this drawing to the local planning authority and the client. Alternatively, a pdf of each SGN can be downloaded by:

1. clicking the image links in the electronic pdf version of this plan;

2. holding a mobile phone QR (Quick Response) code reader over the QR code in the paper version of this plan; or,

3. visiting our website at <https://www.barrelltreecare.co.uk/resources/technical-guidance>

SGN 1

Monitoring tree protection

Always:

have a pre-commencement meeting with the tree consultant before development starts

use the tree consultant to regularly check that protection remains fit for purpose

use the tree consultant to supervise work in RPAs

keep a written record of supervision