

Appendix 7.1: Detailed Construction Dust Assessment Methodology

Source

- 7.1.1 The IAQM dust guidance gives examples of the dust emission magnitudes for demolition, earthworks and construction activities and trackout. These example dust emission magnitudes are based on the site area, building volume, number of HDV movements generated by the activities and the materials used. These example magnitudes have been combined with details of the period of construction activities to provide the ranking for the source magnitude that is set out in Table 7.1.1.

Table 7.1.1 Risk Allocation – Source (Dust Emission Magnitude)

Features of the Source of Dust Emissions	Dust Emission Magnitude
Demolition - building over 75,000 m³, potentially dusty construction material (e.g. concrete), on-site crushing and screening, demolition activities > 12 m above ground level. Earthworks – total site area over 110,000 m², potentially dusty soil type (e.g. clay), >10 heavy earth moving vehicles active at any one time, formation of bunds > 6 m in height. Construction - total building volume over 75,000 m³, activities include piling, on-site concrete batching, sand blasting. Trackout – over 50 HDV outwards movements in any one day, potentially dusty surface material (e.g. High clay content), unpaved road length > 100 m.	Large
Demolition - building between 12,000 to 75,000 m³, potentially dusty construction material and demolition activities 6 - 12 m above ground level. Earthworks – total site area between 18,000 to 110,000 m², moderately dusty soil type (e.g. silt), 5 – 10 heavy earth moving vehicles active at any one time, formation of bunds 3 - 6 m in height. Construction - total building volume between 12,000 and 75,000 m³, use of construction materials with high potential for dust release (e.g. concrete), on-site concrete batching. Trackout – 20 - 50 HDV outwards movements in any one day, moderately dusty surface material (e.g. High clay content), unpaved road length 50 – 100 m.	Medium
Demolition - building less than 12,000 m³, construction material with low potential for dust release (e.g. metal cladding or timber), demolition activities < 6 m above ground, demolition during winter months. Earthworks – total site area less than 18,000 m². Soil type with large grain size (e.g. sand), < 5 heavy earth moving vehicles active at any one time, formation of bunds < 3 m in height. Construction - total building volume below 12,000 m³, use of construction materials with low potential for dust release (e.g. metal cladding or timber). Trackout – < 20 HDV outwards movements in any one day, surface material with low potential for dust release, unpaved road length < 50 m.	Small

Pathway and Receptor - Sensitivity of the Area

- 7.1.2 Pathway means the route by which dust and particulate matter may be carried from the source to a receptor. The main factor affecting the pathway effectiveness is the distance from the receptor to the source. The orientation of the receptors to the source compared to the prevailing wind direction is a relevant risk factor for long-duration construction projects; however, short-term construction projects may be limited to a few months when the most frequent wind direction might be quite different, so adverse effects can potentially occur in any direction from the site.
- 7.1.3 As set out in the IAQM dust guidance, a number of attempts have been made to categorise receptors into high, medium and low sensitivity categories; however there is no unified sensitivity classification scheme that covers the quite different potential effects on property, human health and ecological receptors.
- 7.1.4
- 7.1.5 Table 7.1.2 and Table 7.1.3 sets out the IAQM basis for categorising the sensitivity of people and property to dust and PM₁₀ respectively. Table 7.1.5 sets out the basis for determining the sensitivity of ecological receptors to dust.

Table 7.1.2 Sensitivities of People and Property Receptors to Dust

Receptor	Sensitivity
Principles:- • Users can reasonably expect enjoyment of a high level of amenity; or • the appearance, aesthetics or value of their property would be diminished by soiling; and • the people or property would reasonably be expected to be present continuously, or at least regularly for extended periods as part of the normal pattern of use of the land. Indicative Examples:- • Dwellings. • Museums and other culturally important collections. • Medium and long-term car parks and car showrooms.	Large
Principles:- • Users would expect to enjoy a reasonable level of amenity, but would not reasonably expect to enjoy the same level of amenity as in their home; or • the appearance, aesthetics or value of their property could be diminished by soiling; or • the people or property wouldn't reasonably be expected to be present here continuously or regularly for extended periods as part of the normal pattern of use of the land.	Medium

Indicative Examples:- • Parks. • Places of work.	
Principles:- • the enjoyment of amenity would not reasonably be expected; or • there is property that would not reasonably be expected to be diminished in appearance, aesthetics or value by soiling; or • there is transient exposure, where the people or property would reasonably be expected to be present only for limited periods of time as part of the normal pattern of use of the land. Indicative Examples:- • Playing fields, farmland (unless commercially-sensitive horticultural). • Footpaths and roads. • Short-term car parks.	Small

Table 7.1.3 Sensitivities of People and Property Receptors to PM₁₀

Receptor	Sensitivity
Principles:- • Locations where members of the public are exposed over a time period relevant to the air quality objective (in the case of the 24-hour objective for PM₁₀, a relevant location would be one where individuals may be exposed for eight hours or more in a day). Indicative Examples:- • Residential properties. • Schools, hospitals and residential care homes.	High
Principles:- • Locations where the people exposed are workers and exposure is over a time period relevant to the air quality objective (in the case of the 24-hour objective for PM₁₀, a relevant location would be one where individuals may be exposed for eight hours or more in a day). Indicative Examples:-	Medium

Office and shop workers (but generally excludes workers occupationally exposed to PM₁₀ as protection is covered by Health and Safety at Work legislation).	
Principles:- - Locations where human exposure is transient exposure. - Indicative Examples:- - Public footpaths. - Playing fields, parks. - Shopping streets.	Low

Table 7.1.4 Sensitivities of Ecological Receptors to Dust

Receptor	Sensitivity
Principles:- - Locations with an international or national designation and the designated features may be affected by dust soiling; or - locations where there is a community of a particularly dust sensitive species such as vascular species included in the Red Data List For Great Britain. Indicative Examples:- - Special Area of Conservation (SAC) designated for acid heathlands adjacent to the demolition of a large site containing concrete (alkali) buildings or for the presence of lichen.	High
Principles:- - Locations where there is a particularly important plant species, where its dust sensitivity is uncertain or unknown; or - locations with a national designation where the features may be affected by dust deposition. Indicative Examples:- - Site of Special Scientific Interest (SSSI) with dust sensitive features.	Medium
Principles:- - Locations with a local designation where the features may be affected by dust deposition. Indicative Examples:- - A Local Nature Reserve with dust sensitive features	Low

7.1.6 The IAQM methodology combines consideration of the pathway and receptor to derive the 'sensitivity of the area'. Table 7.1.5 Table 7.1.6 and Table 7.1.7 show how the sensitivity of the area has been derived for this assessment.

Table 7.1.5 Sensitivity of the Area to Dust Soiling Effects on People and Property

Receptor Sensitivity	Number of Receptors ^a	Distance from the Source (m) ^b			
		<20	<50	<100	<250
High	>100	High	High	Medium	Low
	10-100	High	Medium	Low	Low
	1-10	Medium	Low	Low	Low
Medium	>1	Medium	Low	Low	Low
Low	>1	Low	Low	Low	Low
The sensitivity of the area has been derived for demolition, construction, earthworks and trackout. ^a The total number of receptors within the stated distance has been estimated. Only the highest level of area sensitivity from the table has been recorded. ^b For trackout, the distances have been measured from the side of the roads used by construction traffic. The impact declines with distance from the site, and it is only necessary to consider trackout impacts up to 50 m from the edge of the road.					

Table 7.1.6 Sensitivity of the Area to Human Health Impacts

Receptor Sensitivity	Annual Mean PM ₁₀ Concentration ^a	Number of Receptors ^{b, c}	Distance from the Source (m) ^b			
			<20	<50	<100	<250
High	> 32 µg.m ⁻³	>100	High	High	High	Medium
		10-100	High	High	Medium	Low
		1-10	High	Medium	Low	Low
	28 - 32 µg.m ⁻³	>100	High	High	Medium	Low
		10-100	High	Medium	Low	Low
		1-10	High	Medium	Low	Low
	24 - 28 µg.m ⁻³	>100	High	Medium	Low	Low
		10-100	High	Medium	Low	Low
		1-10	Medium	Low	Low	Low
	< 24 µg.m ⁻³	>100	Medium	Low	Low	Low
		10-100	Low	Low	Low	Low
		1-10	Low	Low	Low	Low
Medium	> 32 µg.m ⁻³	>10	High	Medium	Low	Low
		1 – 10	Medium	Low	Low	Low
	28 – 32 µg.m ⁻³	> 10	Medium	Low	Low	Low
		1-10	Low	Low	Low	Low

	< 28 µg.m ⁻³	>1	Low	Low	Low	Low
Low	-	>1	Low	Low	Low	Low

The sensitivity of the area has been derived for demolition, construction, earthworks and trackout.
^a This refers to the background concentration derived from the assessment of baseline conditions later in this report. The concentration categories listed in this column apply to England, Wales and Northern Ireland but not to Scotland.
^b The total number of receptors within the stated distance has been estimated. Only the highest level of area sensitivity from the table has been recorded.
^c For high sensitivity receptors with high occupancy (such as schools or hospitals), the approximate number of occupants has been used to derive an equivalent number of receptors.
^d For trackout, the distances should be measured from the side of the roads used by construction traffic. The impact declines with distance from the site, and it is only necessary to consider trackout impacts up to 50 m from the edge of the road.

Table 7.1.7 Sensitivity of the Area to Ecological Impacts

Receptor Sensitivity	Distance from the Source (m) ^a	
	<20	<50
High	High	High
Medium	Medium	Medium
Low	Low	Low

The sensitivity of the area has been derived for demolition, construction, earthworks and trackout and for each designated site.
^a Only the highest level of area sensitivity has been recorded.

7.1.7 The IAQM dust guidance lists the following additional factors that can potentially affect the sensitivity of the area and, where necessary, professional judgement has been used to adjust the sensitivity allocated to a particular area:

- any history of dust generating activities in the area;
- the likelihood of concurrent dust generating activity on nearby sites;
- any pre-existing screening between the source and the receptors;
- any conclusions drawn from analysing local meteorological data which accurately represent the area; and if relevant the season during which the works will take place;
- any conclusions drawn from local topography;
- duration of the potential impact, as a receptor may become more sensitive over time; and
- any known specific receptor sensitivities which are considered go beyond the classifications given in the table above.

7.1.8 The matrices in Table 7.1.8, Table 7.1.9, Table 7.1.10 and Table 7.1.11 have been used to assign the risk for each activity to determine the level of mitigation that should be applied. For those cases where the risk category is 'negligible', no mitigation measures are required beyond those mandated by legislation.

Table 7.1.8 Risk of Dust Impacts – Demolition

Sensitivity of Area	Dust Emission Magnitude		
	Large	Medium	Small
High	High Risk	High Risk	High Risk
Medium	High Risk	Medium Risk	High Risk
Low	Medium Risk	Low Risk	Medium Risk

Table 7.1.9 Risk of Dust Impacts – Earthworks

Sensitivity of Area	Dust Emission Magnitude		
	Large	Medium	Small
High	High Risk	Medium Risk	Low Risk
Medium	Medium Risk	Medium Risk	Low Risk
Low	Low Risk	Low Risk	Negligible Risk

Table 7.1.10 Risk of Dust Impacts – Construction

Sensitivity of Area	Dust Emission Magnitude		
	Large	Medium	Small
High	High Risk	Medium Risk	Low Risk
Medium	Medium Risk	Medium Risk	Low Risk
Low	Low Risk	Low Risk	Negligible Risk

Table 7.1.11 Risk of Dust Impacts – Trackout

Sensitivity of Area	Dust Emission Magnitude		
	Large	Medium	Small
High	High Risk	Medium Risk	Low Risk
Medium	Medium Risk	Medium Risk	Low Risk
Low	Low Risk	Low Risk	Negligible Risk