

## **METHOD STATEMENT FOR RENDER REMOVAL**

### **Objective:**

To safely and effectively remove the cement render from external walls and surrounding areas, without causing damage to the underlying brickwork.

### **Procedure:**

#### **1. Preparation:**

Begin removal at the top level and work downwards, completing the process section by section.

#### **2. Equipment and Tools:**

- Cold chisel or sharp bolster chisel
- Hammer
- Wire brush or stiff bristle brush
- Hand-held spray bottle filled with clean water

#### **3. Render Removal Process:**

- Using a cold chisel or sharp bolster chisel, along with a hammer, carefully chip away the cement render.
- Hold the chisel at a slight angle to prevent damaging the underlying brickwork.
- Where possible, remove the render in the same layers it was originally applied. This will make the process more manageable and reduce the risk of damage.
- Employ controlled and gentle tapping motions to gradually detach the render from the brickwork. Exercise patience throughout this step to ensure a careful removal process.

#### **4. Cleaning and Finishing:**

- After removing the majority of the render, use a wire brush or stiff bristle brush to scrub away any remaining residue and smooth the exposed surface.
- Rinse the brick surface with clean water using a hand-held spray bottle to remove any loose particles and residue.

#### **5. Inspection:**

- Once the render removal is complete, inspect the exposed brickwork for any defects or damages that were previously hidden.

By following these steps, the render will be removed in a controlled and careful manner, minimising the risk of damage to the underlying brickwork and allowing for thorough inspection and assessment of the external walls and surrounding areas.